

# PRODUCT INFORMATION

## DYNWHITE

DYNWHITE is an optical brightener with a blue cast. It exhausts quickly and completely so that it is best suited for use when bleaching in paddle machines, becks, and jets. Due to DYNWHITE's high affinity to cotton, it can be added to the bath early without fear of rinsing off. It can also be added in the final rinse. In addition, DYNWHITE acts as a good optical brightener on wool.

### SPECIFICATIONS:

|                   |                       |
|-------------------|-----------------------|
| Appearance:       | Clear yellow solution |
| pH:               | 10.5 ± .5             |
| Specific gravity: | 1.06                  |

### APPLICATION:

Due to the ability of DYNWHITE to readily exhaust onto cotton and wool, it is best used in paddle machines, becks, and jets. It is formulated to ensure even application. Use rates are .75% to 1.25% depending on equipment. If added to the final rinse, run for 20 minutes at 120° F.

The data and suggested formulations in this bulletin are based on information believed to be reliable and are offered solely for evaluation, investigation and verification of the numerous factors affecting results. Paradigm Lab's products are sold with the understanding the purchasers will make their own tests to determine the suitability of these products for the particular use. We assume no liability or responsibility for any damage to person or property resulting from or incident to the use of our products.

Statements concerning the use of Paradigm Lab's products are not be construed as recommending the infringement of any patent, and no liability for infringement arising out of any such use is assumed.



**PARADIGM LABS, Inc.**

P.O. BOX 138, PINE GROVE, PA 17963-0138  
(570) 345-2600 – FAX (570) 345-2800